



BNC 5 RC Termination Instructions



1. Slide the color coded heat shrink tubing or BNC strain relief over the cable, then slide the ferrule over the cable. See the top diagram.
2. Carefully strip the end of the coaxial cable to expose the shielding and inner conductor.
3. Insert the center conductor into the center pin.
4. Insert the conductor and pin into the crimp tool (part #100-133-01) with the included die. With the flange on the center pin flush with the edge of the die, crimp using the die's .068" crimp height.



Extron Electronics, USA
1230 South Lewis Street
Anaheim, CA 92805
USA
714.491.1500
Fax 714.491.1517




Extron Electronics, Europe
Beeldschermweg 6C
3821 AH Amersfoort
The Netherlands
+31.33.453.4040
Fax +31.33.453.4050

Extron Electronics, Asia
135 Joo Seng Road, #04-01
PM Industrial Building
Singapore 368363
+65.6383.4400
Fax +65.6383.4664

Extron Electronics, Japan
Daisan DMJ Building 6F
3-9-1 Kudan Minami
Chiyoda-ku, Tokyo 102-0074 Japan
+81.3.3511.7655
Fax +81.3.3511.7656

68-482-01
Rev. D

5. Insert the center pin into the BNC body until the pin meets resistance. Continue firmly pushing the pin into the BNC body until the pin snaps into the detent position.
6. Slide the exposed shielding over the support sleeve of the BNC.
7. Slide the ferrule over the shielding and against the BNC body. Using the die's .213" crimp height, crimp the ferrule.
8. Slide and set the heat shrink tubing or BNC strain relief over the ferrule.



Related tools and parts list:

Crimp tool 100-133-01
BNC 5 RC cable (500' spool) 22-127-02
Male BNC RC connectors (qty. 50) 10-452-01